

# Classroom Configurations

## Level 1 - Basic

- Single or Dual Ceiling Mounted Projector
- Laptop Hook-ups
- Projection Screen (Electric or Manual)
- White Board or Chalk Board
- DVD/VHS Player\*
- Wireless Internet

## Level 2 - Standard

- Single or Dual Ceiling Mounted Projector
- Laptop Hook-ups
- Projection Screen (Electric or Manual)
- White Board or Chalk Board
- DVD/VHS Player
- Wireless Internet
- In-Room Computer (PC or Mac)
- Audio Amplifier w/ Speakers
- Overhead Transparency
- Room Control (AMX or SP Controls)

## Level 3 - Advanced

- Single or Dual Ceiling Mounted Projector
- Laptop Hook-ups
- Projection Screen (Electric or Manual)
- White Board or Chalk Board
- DVD/VHS Player
- Wireless Internet
- In-Room Computer (PC or Mac)
- Audio Amplifier w/ Speakers
- Overhead Transparency
- Room Control (AMX or SP Controls)
- SMART Boards and Sympodium (Interactive Screen)\*
- Document Camera\*
- Microphone\*

## Level 4 - Enhanced

- Single or Dual Ceiling Mounted Projector
- Laptop Hook-ups
- Projection Screen (Electric or Manual)
- White Board or Chalk Board
- DVD/VHS Player
- Wireless Internet
- In-Room Computer (PC or Mac)
- Audio Amplifier w/ Speakers
- Overhead Transparency
- Room Control (AMX or SP Controls)
- SMART Boards and Sympodium (Interactive Screen)
- Document Camera
- Microphone
- Video Conferencing